


New Dead End Marker Installation



Drill a ½” hole in the top of the Dead End marker for wire installation.





Insert a guide wire from the top ½" drilled hole. Pull down through the bottom tab.





Secure the guide wire to the locate wire. Pull them back through the top to eliminate a wire nut.



**Pull both wires back including
slack through the top.**



Set the marker 6"
past the Dead End
cap.



Shade the pipe and Dead End marker while keeping it straight.



Place caution tape



Tie the wire at the top and strip the wire to test continuity.





Installed straight and backfilled.



